



Place alignment tool over valve stem.
 Peel away magnet backing and stick
 magnet at hole in tool.

