

BurnerAlert

"Good design can make a difference, but Great design will change our lives"

Tips and Techniques to Attach BurnerAlert to knobs on a Cooktop

If you have a Cooktop, you may need to remove the escutcheon below the knob to properly mount the magnet. Follow these steps if you are unable to mount the magnet correctly.

Step 1

Picture with knob removed and plastic escutcheon on left side.



Step 2

To remove escutcheon, use a flat head screw driver to gently pry the escutcheon upwards from the opening.

Note: Sometimes you may need to push and pry at the same time.



Step 3

Picture showing escutcheon safely removed. Please store in safe place for future use.



Step 4

Now you are ready to attach the magnet to the Cooktop surface. Please clean the Cooktop surface thoroughly and allow to dry before attaching magnet.



You are finished!

Below is a picture of what your stove knob should look like.

